



Montagesituatie 6 - voorbouw voor het raam binnen  
Montage 6 - avant corps: devant le châssis à l'intérieur  
Installation method 6 - surface-mounted: inside, in front of the window  
Einbauweise 6 - vorbau: drinnen vor dem rahmen  
Tipo de montaje 6 - montaje delante de la ventana en el interior



**RENSON®**  
 Creating healthy spaces

Industriezone "Flanders field"  
 8790 Waregem (Belgium)  
 Tel. 056/62.71.11 Fax. 056/60.28.51

Drawn shout		Date 4/09/2015	Scale 1/3
Fixscreen® 150 <sup>EV0</sup> Softline		Version 1	Formaat A3
MS6/M6/EW6/IM6/TdM6		Page 1/1	