



Montagesituatie 1 - voorbouw: voor het raam buiten  
Montage 1 - avant-corps: devant le châssis à l'extérieur  
Installation method 1 - surface-mounted: outside, in front of the window  
Einbauweise 1 - vorbau: draussen vor dem rahmen  
Tipo de montaje 1 - montaje delante de la ventana en el exterior



**RENSON®**  
Creating healthy spaces  
Industriezone "Flanders field"  
8790 Waregem (Belgium)  
Tel. 056/62.71.11 Fax. 056/60.28.51

Drawn

Date  
7/09/2015

Scale  
1/3

Fixscreen® 150<sup>EV0</sup> Softline

Version  
1

Formaat  
A3

MS1/M1/EW1/IM1/TdM1

Page  
1/1

